





x2= press 2 times


1




2




3




4




5




6



7




Set/work




9




10







11



12



13




14



On

15




16

Historical torque values


Memory

Software version




Peak value

17



Clear Memory

18



Overload

19

